



HELP - SELL & TELL

PAGE 3

CORRECTION 1 - LOAD UP:

PAGE 4

'LOAD UP' IN ISSUE 28/13 BY BOB KITCH WAS INADVERTANTLY CORRUPTED BY ME WHILE TRYING TO FIT PROGRAM ON SINGLE PAGE. A SOLUTION IS PRESENTED AND MY APOLOGIES TO

ENLARGED MEMORY PEEK ROUTINE:

PAGE 4

A USEFULL LITTLE ROUTINE FOR PEEKING AROUND MEMORY, BASIC OR DOS ROMS, ETC. SOME MEMORY ADDRESSES ARE GIVEN FOR YOUR PERUSAL.

FLICKER-FREE GRAPHICS PART II BY BOB KITCH

PAGES 5-6

BOB CONTINUES ON FROM LAST ISSUE FINISHING HIS EXPLANATION OF VZ GRAPHICS AND LIFTING THE VEIL OF MYSTERY FOR MANY OF US.

INVESTIGATING VZ SOUND BY BOB KITCH

PAGES 7-8

AS BOB MENTIONS IN HIS ARTICLE NOT MANY PROGRAMMERS USE SOUND EFFECTIVELY ON THE VZ. BOB PROVIDES A SIMPLE DEMO PROGRAM CALLED 'STARWARS' WITH MORE COMPLEX SOUNDS TO FOLLOW.

CORRECTION 2 - TANDY PR/PATCH: PAGES 9-10 ANOTHER OF BRIAN GREEVE'S PROGRAMS I MANAGED TO CORRUPT IN ISSUE 28/6-7. AGAIN IT WAS THE MACHINE CODE WHICH HAD WRONG ADDRESSES. THE CORRECTED VERSION IS REPRODUCED. MY APOLOGIES AGAIN TO ALL.

ASSEMBLER ROUTINES PART II PAGES 11-13 BY BEN HOBSON

BEN CONTINUES WITH LARGER ROUTINES FOR YOU TO TRY OUT YOUR SKILLS AT ASSEMBLY PROGRAMMING.

MODS TO DSE DISC DATABASE PAGES 14-16 BY JOHN D'ALTON

THOSE WHO WISH TO MODIFY THEIR DSE DISK BASED DATABASE NEED LOCK NO FURTHER AS JOHN PROVIDES THEM INFO ON HOW TO ACCOMPLISH IT.

PROPOSED MEMORY EXPANSION STANDARDS BY JOE LEON

PAGE 17

I'M PLANNING MASSIVE MEMORY EXPANSION FOR THE VZ. I'VE EXPANDED THE VZ MEMORY MAP TO SHOW YOU WHAT I PROPOSE AND WHAT I/O PORTS I INTEND TO USE. FOR THOSE INTERESTED PLEASE CONTACT ME AS SOON AS YOU CAN.

VZ MODEM SOFTWARE AND FAST M/C DISASSEMLER SOFTWARE

PAGE 18

SOFTWARE FOR SALE - PATCH3.3 EXTENDED DOS & MENU-FILE COPIER

PAGE 19

USER GROUPS * NEWS * SUBS

PAGE 20

BELIEVE IT OR NOT:

THERE WAS THIS PERSON WHO SHALL REMAIN NAMELESS WAS REQUESTED BY THE PROGRAM HE WAS USING TO 'PRESS ANY KEY TO PROCEED' WHICH HE COULDN'T FIND, SO HE TOOK HIS COMPUTER BACK TO THE SHOP FOR ONE WITH AN 'ANY' KEY.

DISCLAIMER: EVERY EFFORT IS MADE TO INSURE THE ACCURACY OF INFORMATION CONTAINED WITHIN BE IT GENERAL, TECHNICAL, PROGRAMMING, ETC. NO PESPONSIBILITY CAN BE ACCEPTED BY HUNTER VALLEY VZ USERS' GROUP OR AUTHOR AS A RESULT OF APPLYING SUCH INFORMATION IN PRACTICE.

CONGRATULATIONS: ON THE PRODUCTION OF THE FOURTH ANNIVERSARY EDITION. I PERSONALLY ACKNOWLEDGE THIS IS DUE MOSTLY TO YOUR EFFORTS. BRIAN GREEVE.

THANKS BRIAN FOR YOUR WORDS OF PRAISE WHICH IS GREATLY APPRECIATED, BUT ANY PUPLICATION IS ONLY AS GOOD AS ITS COTRIBUTORS. I WAS LUCKY IN HAVING THE SUPPORT OF HIGH CALIBRE CONTRIBUTORS LIKE YOURSELF AND MANY OTHERS AS WELL. JOE LEON, EDITOR.

FOURTH ANNIVERSARY: WHEN I FIRST STEPPED IN DECEMBER 1986 I NEVER ENVISAGED THAT I'LD BE STILL EDITING FOUR YEARS LATER. FROM THE FIRST TO THE CURRENT ISSUE I'VE TRIED TO PRODUCE THE JOURNAL TO THE BEST OF MY ABILITIES AND I FIND THAT EVEN AFTER ALL THIS TIME AS EDITOR I STILL ENJOY DOING IT.

In the last 12 months I nearly gave it all up several times for personal reasons, but things are starting to look up and would you believe two issues in two months. Looks like I'll be able to catch up soon. Like anyone else I make mistakes and there have been a few lately and I find I'm learning because of them.

THE JOURNAL HAS GIVEN ME A GREAT DEAL OF PERSONAL SATISFACTION, SELF ESTEEM AND A SENSE OF ACCOMPLISMENT, BUT MOST IMPORTANT OF ALL ONE WAY OR ANOTHER I'VE MADE CONTACT WITH MANY PERSONS VIA THE POST, PHONE OR PERSONALLY AND SHARED A COMMON INTEREST, THE MIGHTY VZ.

HELP WITH ARTICLES: I'M RUNNING SHORT OF ARTICLES AGAIN FOR THE JOURNAL SO IF YOU CAN HELP OUT HOWEVER SMALL YOUR CONTRIBUTION IT WOULD BE APPRECIATED. REMEMBER THIS IS YOUR JOURNAL AND AS THE SAYING GOES MANY HANDS MAKE LIGHT WORK AND IT WOULD MAKE MY JOB LOTS EASIER. SO SHARPEN YOUR FINGERS AND START TYPING AWAY.

OPEN INVITATION: OUR CLUB DOORS ARE OPEN TO ALL VISITORS REGARDLESS OF GEOGRAPHY. SO IF YOU ARE PASSING THROUGH OR HOLIDAYING NEARBY, THEN GIVE US A CALL EVEN IF IT'S NOT CLUB MEETING TIME. WE'LL BE GLAD TO SEE YOU.

WANTED: A CHEAP BUT OK 64K RAM PACK.

PHOTOCOPIES OF: AEM ARTICLES ON VZ, EG: APRIL 88. EA JULY 81, GP-100 REVIEW AND VZ. ETI MARCH 84 STEVE OLNEY ON THE VZ. ETI-687 VZ200 34K SUPER DUPER VZ. ETI OCT 84 RITTY. JULY 85 AND ANY OTHER ARTICLES UP TO JUNE 88 (ON VZ).

DAVID MAUNDER 'LYNDONDALE' BORAH CREEK ROAD QUIRINDI 2343 PHONE: (067) 461 711 AFTER 4 PM.

WANTED TO SWAP: VZ 300 PCB (NO CASE OR KEYBOARD), JOYSTICK INTERFACE WITH ONE JOYSTICK; 9 X 6116 2K RAM CHIPS, Z80A, 2716 EPROM, 2 X 482764 EPROMS, PLUS VARIOUS IC'S LIKE 74LS138, 74LS157. ALL CHIPS ARE FROM A DEFUNCT MICROBEE AND ARE SOLDERED EXEPT FOR THE Z80A AND THE EPROMS. THE VZ 300 ONLY NEEDS A U14 IC (GA004).

SWAP FOR: VZ 200 IN WORKING CODITION WITH OR WITHOUT KEYBOARD. IF THIS DEAL DOES NOT PLEASE THEN CONTACT ME ANYWAY AS I HAVE OTHER GOODIES THAT I WILL THROW IN TO COMPLETE THE DEAL.

BEN HOBSON PO BOX 255 QUIRINDI 2343 - PHONE: (067) 462 076)

COPYRIGHT - THE HUNTER VALLEY VZ JOURNAL IS SUBJECT TO COPYRIGHT AND NO MATERIAL IN THE JOURNAL MAY BE REPRODUCED IN PART OR WHOLE WITHOUT THE CONSENT OF THE HUNTER VALLEY USERS' GROUP OR THE AUTHOR WHO RETAINS COPYRIGHT.

The program will not load any HI-RES screens into memory and more likely will hang up. When editing I shortened the start of the program so it would fit on one page. Even though the warning was in line 1020 somehow I missed it. My apologies to Bob and our readers. To make up for it I present a solution so you can fix it up.

LOAD LOAD UP AND TYPE IN THE LITTLE PROGRAM BELOW AND THEN SAVE THE ALTERED PROGRAM. NEXT TYPE IN GOTO 4000 AND PRESS RETURN. WHAT WE'LL BE TRYING TO DO IS TO FIND OUT THE POKE ADDRESSES FOR THE LETTER A AND H IN THE CHARACTERS 'ABCDEFGH' IN LINE 1000. YOU'LL SEE THREE COLUMNS ON THE SCREEN.

```
FIRST COLUMN = MEMORY ADDRESS OF THE CHARACTER.
SECOND COLUMN = ASCII CODE OF THE CHARACTER.
THIRD COLUMN = CHARACTER.
```

USING THE SPACE KEY TO START/STOP CONTINUE TILL THE LETTERS ABCDEFGH ARE DISPLAYED ON THE SCREEN IN THE THIRD COLUMN. WRITE DOWN THE ADDRESSES FOR THE LETTERS 'A' AND 'H' AND PRESS 'Q' TO QUIT. NEXT LIST LINE 1000. ENTER THE TWO NEW ADDRESSES OVER THE OLD ONES AND THEN LIST LINE 2100. Type IN THE NEW ADDRESS FOR 'A' OVER THE OLD ONE AND THAT COMPLETES THE CORRECTIONS. THE PROGRAM SHOULD WORK AS DESIGNED NOW. ANY TIME YOU ALTER LINES 10 TO 1000 YOU HAVE TO CHANGE THE ADDRESS FOR 'A' IN LINE 2100 USING THE MEMORY PEEK ROUTINE TO FIND THE NEW ADDRESS FOR 'A' FIRST.

```
3090 '
4000 CLS:POKE30777,1:PRINT@3, "SPACE START/STOP Q-QUIT"
4010 PRINT:FORL=31800 TO 31900
4015 PRINT TAB(9) USING"###### ";L;
4020 PRINT USING" ### ";PEEK(L);
4030 IF PEEK(L)<32 THEN PRINT:GOTO 4050
4040 PRINT USING"%%";CHR$(PEEK(L))
4050 IF INKEY$=" "THEN 4060 ELSE IF INKEY$="Q"THEN 4070
4060 IF INKEY$=""THEN 4050 ELSE NEXT
4070 CLS:END
```

ENLARGED MEMORY PEEK ROUTINE:

```
110 PRINT@98, ""; : INPUT "ENTER START ADDRESS "; SA
120 PRINTA162, " :: INPUT "ENTER END ADDRESS "; EA
130 IF EAK=SA THEN 120
140 IF SA>32767 THEN SA=SA-65536
150 IF EA>32767 THEN EA=EA-65536
180 PRINT: FORL = SA TO EA: PRINTTAB(9) USING "###### "; L;
190 PRINT USING"### ";PEEK(L);
200 IF PEEK(L) <32 THEN PRINT:GOTO 220
210 PRINT USING "%%"; CHR$ (PEEK (L))
220 IF INKEY$=" "THEN 230 ELSE IF INKEY$="Q"THEN 240
   IF INKEYS=""THEN 220 ELSE NEXT
250 POKE 30777,35:SOUND30,1
260 IF INKEYS=CHR$ (13) THEN 100 ELSE 260
   SOME INTERESTING PEEK ADDRESSES
<u>୍</u>ଟ୍ର
290 ADDRESSES 270 TO 300 & 5710 TO 6180
    'ADDRESSES 6420 TO 6460 & 17190 TO 17270
500 I
```

WE NOW NEED TO CONSIDER THE TIMING OF THE CPU IN DOING A 2K BLOCK MOVE OPERATION. THE Z80 IN THE VZ300 RUNS AT 3.54 MHz (THE VZ200 RUNS AT 3.58 MHz). THE FOLLOWING TABULATION INDICATES THE TIMING OF THE BLOCK MOVE —

OPCODE	T-9	STATES M-CYCLES
OI	4	1
LD HL	10	3
LD DE	10	3
LD BC	10	3
LDIR	21>	(2 0 47+16 5x2 0 47+4
	IF	BC=0 THEN T=16 AND M=4
	IF	BC<>0 THEN T=21 AND M=5
EI	4	1
RET	10	3
	43051	10253

TIME TO EXECUTE IS 43051/3.54E6 SEC. = 12.16 MSEC. TO BLOCK MOVE A 2K SCREEN. THIS IS LONGER THAN THE 7.69 MSEC. MENTIONED ABOVE. A 2K BLOCK MOVE WILL CAUSE HASH TO APPEAR ON THE SCREEN BECAUSE A TIMING CONFLICT IN THE WRITE BY THE Z80 AND THE READ BY THE VDG OCCURS. FOR THOSE OF YOU WHO HAVE SEEN THROWUP OPERATE, YOU WILL HAVE SEEN THIS EFFECT IN THE "PLAIN MODE" OF OPERATION.

So, what have we learnt thus far about graphics on the VZ? We have discovered how the Z80 and the 6847 VDG interact with VRAM to make the screen display. We have also seen why "hash" appears on the screen. We have also analysed the timing of screen transfers from a buffer and discovered that about 1K of data can be block moved during the screen refresh period. In some previous articles in user Group Newsletters, I have described the Maskable Interrupt System used in the VZ. Let's put all of this together to make a hash-free display system. Such a system is used in Livenup.

INTERRUPT-DRIVEN SCREEN BUFFER.

I TRUST THAT THE FOREGOING DISCUSSION MAKES IT APPARENT THAT, WHEN WRITING PARTICULARLY GRAPHICS PROGRAMS, IT IS BETTER TO HAVE THE Z80 UPDATING A BUFFER AREA IN MEMORY RATHER THAN DIRECTLY WRITING TO VRAM. THIS IS THE ONLY TECHNIQUE THAT WILL REMOVE THE HASH FROM THE VZ DISPLAY. THIS PROGRAMMING TECHNIQUE HAS THE ADDED ADVANTAGE THAT INTERRUPTS CAN BE DISABLED AND PROCESSING SPED UP CONSIDERABLY BY BYPASSING SOME OF THE VZ'S OVERHEADS SUCH AS KEYBOARD SCANNING.

TO TRANSFER THE BUFFER INTO VRAM EMPLOYS A FEW OTHER PROGRAMMING TRICKS. CLEARLY A 2K HI-RES SCREEN MUST BE MOVED IN TWO HALVES AS THERE IS SIMPLY INSUFFICIENT TIME DURING THE "INVISIBLE" PORTION OF THE DISPLAY UPDATE TO MOVE IT IN A SINGLE 2K BLOCK.

THE METHOD THAT I HAVE USED ENABLES THE MASKABLE INTERRUPTS ON THE Z80 AND RESETS THE INTERRUPT VECTOR TO POINT TO THE SCREEN UPDATE ROUTINES. TO ALLOW SUFFICIENT TIME FOR THE TWO HALVES OF THE BUFFER TO BE RELOCATED, A SUITABLE DELAY OR PAUSE ROUTINE MUST BE ENTERED. ONE SUCH ROUTINE OCCURS IN THE DOS ROM AND CAN BE CONVENIENTLY CALLED WITH THE DELAY DURATION IN MSEC. PASSED IN THE BC REGISTER. IF DOS IS NOT INSTALLED ON THE VZ THEN ANOTHER DELAY ROUTINE OCCURS AT 0060H IN ROM. THE VALUE PASSED IN BC IS NOT IN MSEC. HOWEVER. THE DELAY DURATION VALUE CAN ALSO BE USED TO CONTROL THE SPEED AND SMOOTHNESS AT WHICH GRAPHICS FLOW ACROSS THE SCREEN.

THE SCLUTION - AN ASSEMBLER LISTING.

SO WHAT DOES THE ASSEMBLER LISTING OF ALL OF THIS LOOK LIKE? BY REFERRING TO A LISTING OF MOVE USED BY LIVENUP, SOME CLARITY MAY BE SHED ON THE SUBJECT FOR CONFUSED READERS!

THE LISTING FALLS NATURALLY INTO FOUR SECTIONS. THE FIRST IS THE MAINLINE CALLING SEQUENCE AND IS NOT DETAILED HEREIN AS THIS WILL VARY ACCORDING TO THE APPLICATION. THE SECOND PORTION IS A PAUSE AND DISPLAY SUBROUTINE CALLED DPLY WHICH POINTS THE INTERRUPT VECTOR AT THE MOVE ROUTINES, ENABLES INTERRUPTS AND THEN ENTERS A PAUSE ROUTINE DURING WHICH TIME THE TRANSFER OF THE BUFFER INTO VRAM OCCURS. THE THIRD AND FOURTH PORTIONS MOVE THE TOP AND BOTTOM HALVES OF THE BUFFER RESPECTIVELY. THEY ARE CALLED FROM THE INTERRUPT VECTOR LOCATED AT 787DH DURING THE PAUSE CYCLE AND WHEN INTERRUPTS ARE ENABLED. THEY ARE ACCURATELY TIMED AND INITIATED BY THE *FS SIGNAL WHICH CALLS THE INTERRUPT HANDLING ROUTINE. THE MOVE OCCURS DURING THE "INVISIBLE" PORTION OF THE DISPLAY UPDATE AND ELIMINATES HASH.

```
MAINLINE OF PROGRAM ; CALLING SEQUENCE.
                                                                                          ;DISABLE INTERRUPTS TO SPEED UP PROCESSING.
                             DO CALCULATIONS ETC. ; UPDATE VRAM.
                            CALL DPLY ; UPDATE SCREEN DISPLAY.
                                                                                         ; ENABLE INTERRUPTS TO RESUME OTHER CHOIRS.
                              . . . . . . . . .
                             ENO
          VRAM EQU 7000H

SSCN EQU 08200H

SZSC EQU 0800H

HSZC EQU 0400H

CHARLE OF SIZE OF SCREEN/BUFFER.

CHARLE OF
                                                                                        ; DELAY DURATION IN MSEC. TO PERMIT SCREEN UPDATE.
           DPLY LD A, JMP

LD BC, MTOP

LD (IVEC+1), BC

LD (IVEC), A

;PUT OPCODE FOR JUMP INTO A.
;POINT TO START OF MOVE TOP-HALF OF BUFFER ROUTINE.
;RESET INTERRUPT VECTOR.
;DITTO - NOW POINTS TO MTOP.
;FNARIF INTERRUPTS SO THAT INTERRUPT VECTOR IS SCANN
                                                                                        ; ENABLE INTERRUPTS SO THAT INTERRUPT VECTOR IS SCANNED.
                          LD BC, DURD ;DELAY DURATION IN MSEC.
CALL DLAY ;GO OFF INTO DELAY ROUTINE ALLOWING SUFFICIENT TIME FOR
   SCREEN TO BE UPDATED FROM BUFFER.
                         \mathsf{DI}
                                                                                         ;DISABLE INTERRUPTS TO PREPARE FOR RESUMING MAINLINE
   PROGRAM.
                          RET
                                                                                       GO BACK TO CALLING MAINLINE TO UPDATE BUFFER.
          ### SET SOURCE TO START OF BUFFER.

LD DE, VRAM 
LD BC, HSZC 
SET SIZE TO HALF OF BUFFER/SCREEN SIZE.

**SET SIZE TO HALF OF SCREEN.**
                         LDIR
                                                                                    ; UPDATE TOP-HALF OF SCREEN.
                         DI
                                                                                    ;DISABLE INTERRUPTS, AS INTERRUPT VECTOR IS TO BE RESET.
                         DISABLE INTERRUPTS. AS INTERRUPT VECTOR IS TO BE RESET LD BC, MBOT ;POINT TO START OF MOVE BOTTOM-HALF OF BUFFER ROUTINE.

CITY (IVEC+1), BC ;RESET INTERRUPT VECTOR.
                         EI
                                                                                      ; ENABLE INTERRUPTS SO THAT DELAY ROUTINE CAN CONTINUE.
                         RET
                                                                                      ;GO BACK TO INTERRUPT HANDLER.
         MBOT LD HL, SSCN+HSZC ;SET SOURCE TO HALF-WAY THROUGH BUFFER. LD DE, VRAM+HSZC ;SET DESTINATION SIMILARLY. ;SET SIZE.
LDIR ;UPDATE BOTTOM-HALF OF SCREEN.

DI ;DISABLE INTERRUPTS AS INTERRUPT VECTOR IS TO BE RESET.

LD A, TURN ;PUT OPCODE FOR A RETURN INTO A.

LD (IVEC), A ;RESET INTERRUPT VECTOR SO THAT SCREEN UPDATING

ROUTINES ARE NOT ENTERED DURING REMAINDER OF DELAY ROUTINE.
                        EI
                                                                          :ENABLE INTERRUPTS SO THAT DELAY ROUTINE CAN CONTINUE.
                        RET
                                                                                       GO BACK TO INTERRUPT HANDLER.
```

SOUND OR MUSIC HAS NOT BEEN FEATURED IN MOST VZ SOFTWARE. DURING A NUMBER OF BRIEF ARTICLES, I WILL DISCUSS THE GENERATION OF SOUNDS ON THE VZ. I WILL ALSO PROVIDE SOME THOUGHT PROVOKING PROGRAM LISTINGS. I THOROUGHLY ENJOY COMPUTER GENERATED OR SYNTHESIZED MUSIC. THE VZ CAN ALSO BE USED AS A CONTROLLER IN MUSIC GENERATION.

BACKGROUND

THE VZ TONE GENERATOR USES A SMALL PIEZO SPEAKER CONNECTED ACROSS TWO BITS OF THE I/O LATCH. CLEARLY THERE IS NOT MUCH HARDWARE INVOLVED - WHICH IS WHY ALL THE SOUND GENERATION DEPENDS UPON SOFTWARE.

THE OBVIOUS SHORTCOMINGS OF THIS METHOD ARE TWOFOLD:

FIRSTY, ONLY SINGLE VOICED MELODIES CAN BE PLAYED AND, SECONDLY, NOTHING ELSE CAN BE DONE WHILST PLAYING AS THE Z80 IS FULLY OCCUPIED. TO IMPROVE UPON THIS SITUATION, SOME ADDITIONAL HARDWARE IS REQUIRED, SUCH AS AN ADDITIONAL SOUND GENERATING CHIP.

TONE GENERATION IS A PERIODIC PHENOMENON AND REQUIRES FREQUENT SETTING AND RESETTING OF THE TWO BITS DRIVING THE SPEAKER. THE VZ'S I/O LATCH IS ADDRESSED AT 6800H. BITS 0 AND 5 DRIVE THE SPEAKER IN A PUSH-PULL MODE. THIS MEANS THAT BITS 5 AND 0 MUST BE COMPLIMENTARY TO DRIVE THE SPEAKER. THE SAME LATCH ALSO CONTROLS THE CASSETTE PORT ON THE VZ AND THIS MAY BE USED FOR RECORDING TONES. BITS 1 AND 2 SIMILARLY DRIVE THE CASSETTE PORT.

THE FASTER THAT BITS 0 AND 5 ARE SWITCHED (SET AND RESET), THE HIGHER THE PITCH (OR FREQUENCY) OF THE TONE THAT WILL BE ISSUED FROM THE VZ'S SPEAKER. THE NORMAL AUDIO SPECTRUM EXTENDS FROM 20 TO 200000 HERTZ OR CYCLES PER SECOND. FOR EXAMPLE, THE "MIDDLE C" ON A PIANO IS 262 HZ OR A PERIOD OF 3.8 MILLISEC. (PERIOD IS THE RECIPROCAL OF FREQUENCY)

THE QUALITY OR TIMBRE OF THE SOUND IS QUITE INDEPENDANT OF PITCH OR FREQUENCY. A TRUMPET SOUNDS QUITE DISTINCTIVE TO A TROMBONE BECAUSE OF THE DIFFERENT TIMBRE OF EACH INSTRUMENT. MATHEMATICALLY THIS MAY BE EXPRESSED AS THE PRESENCE OF "HARMONICS" BEING PRESENT ABOVE THE FUNDAMENTAL FREQUENCY. IN TERMS OF SOUND GENERATION, THIS IS CHARACTERIZED BY THE DUTY CYCLE OF THE WAVEFORM. NORMALLY IN THE VZ, THE TWO BITS AT 6800H ARE SWITCHED ON AND OFF AT THE SAME RATE. THIS RESULTS IN A SQUARE WAVE FORM OF OUTPUT THAT IS DEFFICIENT IN HARMONICS. THE DUTY CYCLE IS 50:50. THIS MEANS THAT THE "ON PERIOD" IS OF THE SAME DURATION AS THE "OFF PERIOD". BY VARYING THIS RATIO, SOME INTERESTING SOUNDS CAN BE GENERATED.

A THIRD PARAMETER GOVERNS SOUND. IN ADDITION TO PITCH AND TIMBRE, LOUDNESS PLAYS A PART. UNFORTUNATELY ON THE VZ THIS CANNOT BE VARIED INDEPENDANTLY OF TIMBRE.

VZ SOUND SYNTHESIS.

THE SIMPLEST WAY TO GENERATE SOUND ON THE VZ IS TO USE THE FACILITIES PROVIDED BY THE SOUND COMMAND IN THE BASIC INTERPETER. THIS IS VERY USEFUL AND CONVENIENT AND WAS ONE OF THE "IMPROVEMENTS" THAT THE VZ HAD OVER THE EARLIER TRS-80 COMPUTERS.

ENTER MY LISTING ENTITLED "STARWARS" AND LISTEN TO THE TUNE.

THERE ARE A COUPLE OF POINTS TO OBSERVE IN THIS TUNE. THE VOLUME AND TONE (TIMBRE) OF THE MELODY CANNOT BE VARIED. IN A COUPLE OF PLACES, THE TIMING OF THE TUNE IS DELAYED WHILST THE INTERPETER IS WRITING TO THE SCREEN. THE TIMING IS ALSO VARIED IN A COUPLE OF OTHER PLACES AS TRIPLETS (A NOTE OF A CERTAIN DURATION) ARE USED AND THESE ARE NOT PROVIDED IN THE INTERPETER. ALL-IN-ALL THOUGH, THE VZ MAKES A PRETTY FAIR FIST OF IT.

NEXT TIME WE WILL DISCUSS THE BASIC INTERPETER AND ACTUALLY THE MEANS BY WHICH SOFTWARE COMMANDS ARE CONVERTED IN TO PHYSICAL SOUND WAVES.

* * * STAR WARS THEME BY BOB KITCH * * *

```
010 *************
 020 '*
         STAR WARS THEME
 030 '*
          BY BOB KITCH
 040 '*
              20/8/90
 050 **********
 060 A%=PEEK (30777): POKE 30777,1: POKE 30744,1: 'SPEEDS UP PRINTING.
 070 CLS:CLS:PRINT0480, "A LONG TIME AGO"
 080 PRINT"IN A GALAXY FAR, FAR AWAY"
 090 PRINT"A GREAT ADVENTURE TOOK PLACE.";:FOR I=0 TO 1000:NEXT I
 100 SOUND 6,1;6,1;6,1
 105 PRINT: PRINT: PRINT" IT IS A PERIOD OF CIVIL WAR.";
 110 SOUND 11,4;18,4
 120 SOUND 16,1;15,1;13,1;23,4;18,2
 130 SOUND 16,1;15,1;13,1;23,4;18,2
 140 SOUND 16,1;15,1;16,1;13,4;6,2;6,1
 145 PRINT: PRINT: PRINT "REBEL SPACESHIPS"
 146 PRINT"FIGHTING FROM A HIDDEN BASE";
 150 SOUND 11,4;18,4
 160 SOUND 16,1;15,1;13,1;23,4;18,2
 170 SOUND 16,1;15,1;13,1;23,4;18,2
 180 SOUND 16,1;15,1;16,1;13,4;6,2;6,1
 185 PRINT:PRINT"HAVE WON THEIR FIRST VICTORY";
 190 SOUND 8,3;8,1;16,1;15,1;13,1;11,1
 200 SOUND 11,1;13,1;15,1;13,2;8,1;10,2;6,2;6,1
 210 SOUND 8,3;8,1;16,1;15,1;13,1;11,1
 220 SOUND 18,1;13,1;13,4;6,2;6,1
 225 PRINT: PRINT "AGAINST THE EVIL"
 226 PRINT"GALACTIC EMPIRE."
 230 SOUND 8,3;8,1;16,1;15,1;13,1;11,1
240 SOUND 11,1;13,1;15,1;13,2;8,1;10,2;18,2;18,1
250 SOUND 23,2;21,1;20,2;18,1;16,2;15,1;13,2;11,1
260 SOUND 18,5
300 SOUND 6,1;6,1;6,1
305 PRINT:PRINT:PRINT"DURING THE BATTLE";
310 SOUND 11,4;18,4
320 SOUND 16,1;15,1;13,1;23,4;18,2
330 SOUND 16,1;15,1;13,1;23,4;18,2
340 SOUND 16,1;15,1;16,1;13,4;6,2;6,1
345 PRINT: PRINT "REBEL SPIES MANAGED TO STEAL"
346 PRINT"SECRET PLANS TO THE EMPIRE'S
347 PRINT"ULTIMATE WEAPON";
350 SOUND 11,4;18,4
360 SOUND 16,1;15,1;13,1;23,4;18,2
370 SOUND 16,1;15,1;13,1;23,4;18,2
380 SOUND 16,1;15,1;16,1;13,4;18,2
385 PRINT:PRINT:PRINT"
                                 THE DEATH STAR. ":PRINT
390 SOUND 23,8
400 SOUND 23,1;23,1;23,1
410 SOUND 23,1
415 PRINT"- AN ARMOURED SPACE STATION"
416 PRINT"WITH ENOUGH POWER TO DESTROY AN ENTIRE PLANET.";
420 FOR I=0 TO 2000:NEXT I
430 CLS:PRINTa195, "MAY THE FORCE BE WITH YOU."
440 FOR I=0 TO 1000:NEXT I
450 PRINTa430,""
460 POKE 30777,A%:POKE 30744,0
500 END
```

```
001
                       002:
                              *** TANDY ***
                       003
                       004 ; VERSION OF THE EPSON PATCH
                       005 ; FOR THE TANDY PRINTER
                       006 ; JULY 13 1989
                      007;
AA4F 3E C3
                      800
                                LD
                                      A,0C3H
AA51 32 C1 79
                      009
                                      (79C1H),A
                                LD
AA54 21 66 AA
                                      HL,STRT
(79C2H),HL
                      010
                                LD
AA57 22 C2
            79
                      011
                                LD
AA5A CD C9 01
                      012
                                CALL 01C9H
AA5D 21
        11
            AB
                      013
                                LD
                                      HL, MES
AA60 CD A7
            28
                      014
                                CALL 28A7H
AA63 C3
        19 1A
                      015
                                JP
                                      1A19H
AA66 3A 9C 78
                      016 STRT LD
                                      A, (789CH)
AA69 33
                      017
                                INC
                                      SP
AA6A 33
                      018
                                INC
                                      SP
AA6B B7
AA6C 79
                      019
                                OR
                                      Α
                      020
                                      A,C
                                LD
AA6D C1
                                POP
                                      BC
                      021
AA6E FA 54 3B
                                JP
                      022
                                      M, 3B54H
AA71 CA 3A 03
                      023
                                JP
                                      Z,033AH
AA74 E5
                      024
                                PUSH HL
AA75 F5
                      025
                                PUSH AF
AA76 21 98 78
                      026
                                      HL,789BH
                                LD
AA79 34
AA7A 7E
                      027
                                INC
                                      (HL)
                      028
                                LD
                                      A,(HL)
AA7B FE 4F
                      029
                                CP
                                      4FH
AA7D 20 07
                      030
                                JR
                                      NZ, POP
AA7F 36 00
                      031
                                LD
                                      (HL),0
AA81 3E 0D
                      032
                                LD
                                      A, ODH
AA83 CD BA 3A
                      033
                                CALL 3ABAH
AA86 F1
                      034 POP
                                POP
                                      AF
AA87 E1
                      035
                                POP
                                      HL
AA88 FE OD
                      036
                                CP
                                      ODH
AA8A 20 07
                                JR
                      037
                                      NZ, FORD
AA8C
     3E 00
                      038
                                LD
                                      A,0
AA8E 32 9B 78
                      039
                                LD
                                      (789BH).A
AA91 3E 0D
                                      A,ODH
                      040
                                LD
AA93
     B7
                      041 FORD OR
                                      Δ
AA94 FA 9A AA
                      042
                                JP
                                     M, TWOD
AA97 C3 BA 3A
                                JP
                     043
                                      3ABAH
AA9A CB 77
                      044 TWOD BIT
                                      6,A
AA9C 28 3A
                     045
                                      Z,GRPH
                                JR
AA9E E6 3F
                               AND
                      046
                                      3FH
AAAO F5
                      047
                                PUSH AF
AAA1 C5
                      048
                                PUSH BC
AAA2 D5
                                PUSH DE
                      049
AAA3 E5
                      050
                                PUSH HL
AAA4 6F
                      051
                                LD
AAA5 26 00
                      052
                                LD
                                     H,0
AAA7
     3E 12
                      053
                                LD
                                      A.12H
AAA9 CD BA 3A
                      054
                                CALL 3ABAH
AAAC 06 04
                      055
                                LD
                                      8,4
AAAE E5
                      056
                                PUSH HL
AAAF D1
                      057
                                POP
                                     DE
AABO B7
                      058
                                OR
AAB1 ED 5A
                                ADC
                      059 LP
                                     HL, DE
AAB3 10 FC
                      060
                                DJNZ LP
AAB5 E5
                      061
                                PUSH HL
```

```
AAB6 C1
                                  POP
                       062
                                       BC
 AAB7 21
          94 3B
                       063
                                       HL,3B94H
                                  LD
 AABA 09
                       064
                                  ADD
                                       HL, BC
 AABB 3E FF
                       065
                                       A, OFFH
                                  LD
AABD CD BA
             3A
                       066
                                  CALL 3ABAH
AACO 06 05
                       067
                                  LD
                                       B,5
AAC2 7E
                       068 LP1
                                  LD
                                       A,(HL)
AAC3 23
                       069
                                  INC
                                       HL
AAC4 CD BA
                       070
                                 CALL 3ABAH
AAC7
      10
         F9
                       071
                                  DJNZ LP1
AAC9 3E
         FF
                       072
                                 LD
                                       A,OFFH
AACB CD
         BA 3A
                       073
                                  CALL 3ABAH
AACE 3E
         1 E
                       074
                                 LD
                                       A,1EH
AADO CD BA 3A
                       075
                                 CALL 3ABAH
AAD3 E1
                                 POP
                       076
                                       HL
AAD4 D1
                       077
                                 POP
                                       DE
AAD5 C1
                       078
                                 POP
                                       BC
AAD6 F1
                       079
                                 POP
                                       AF
AAD7 C9
                       080
                                 RET
AAD8 C5
                       081 GRPH PUSH BC
AAD9 47
                       082
                                 LD
                                       8,A
AADA 3E 12
                       083
                                 LD
                                       A,12H
AADC CD BA
             3A
                       084
                                 CALL 3ABAH
AADF 78
                       085
                                 LD
                                       A,B
AAEO E6
         OF
                       086
                                 AND
                                       OFH
AAE2
     E5
                       087
                                 PUSH HL
AAE3 CB
         27
                       880
                                 SLA
                                       Α
AAE5 4F
                       089
                                 LD
                                       C,A
AAE6 3E 1E
                       090
                                 LD
                                       A,1EH
AAE8 91
                       091
                                 SUB
AAE9 4F
                                       C,A
                       092
                                 LD
AAEA AF
                       093
                                 XOR
                                       Α
AAEB 47
                       094
                                       B,A
                                 LD
AAEC 21
         AF 02
                       095
                                 LD
                                       HL, O2AFH
AAEF 09
                       096
                                 ADD
                                       HL,BC
AAFO 7E
                       097
                                 LD
                                       A,(HL)
AAF1 47
                       098
                                 LD
                                       B,A
AAF2
     23
                       099
                                 INC
                                       HL
AAF3 7E
                       100
                                 LD
                                       A,(HL)
AAF4 4F
                       101
                                       C,A
                                 LD
AAF5
     78
                       102
                                 LD
                                       A.B
AAF6 CD BA 3A
                       103
                                 CALL 3ABAH
AAF9 CD BA 3A
                       104
                                 CALL 3ABAH
AAFC
     CD BA 3A
                       105
                                 CALL 3ABAH
     79
AAFF
                       106
                                 LD
                                       A,C
ABOO CD BA
                                 CALL 3ABAH
            3A
                       107
ABO3 CD BA
            3A
                       108
                                 CALL 3ABAH
ABO6 CD BA
            3A
                       109
                                 CALL 3ABAH
AB09 3E
         1E
                       110
                                 LD
                                       A,1EH
ABOB CD BA
            3A
                       111
                                 CALL 3ABAH
ABOE E1
                                 POP
                       112
                                      HL
ABOF C1
                       113
                                 POP
                                      BC
AB10 C9
                       114
                                 RET
AB11 0D
                       115 MES
                                 DEFB ODH
                       116
                                 EQU
                                      $
                       117
AB12
         TEXT
                           *TANDY PRINTER PATCH LOADED*
AB2C OD
                                 DEFB ODH
                       118
AB2D 00
                       119
                                 NOP
AB2E 00
                       120
                                 NOP
AB2F 00
                       121
                                 NOP
BYTES FREE :- 21359 ERRORS : 00000
```

WORKING OUT CODES FOR SCREEN ADDRESSES

UNLIKE BASIC, WHICH ADDRESSES EACH INDIVIDUAL DOT WITH THE SET COMMAND, ASSEMBLER ADDRESSES GRAPHICS BY BYTES. A BYTE CONSISTS OF FOUR DOTS. EACH DOT HAS TWO BITS TO INDICATE THE COLOUR.

SO FOR ONE ADDRESS-LETS JUST SAY 7000H (THE FIRST SCREEN ADDRESS).

(PIXEL NUMBER) 1 2 3 4 (CONTENTS) * 00 * 10 * 11 * 01 *

COLOR GREEN RED BLUE YELLOW BUFF MAGENTA ORANGE CYAN (BINARY NUMBER) 00 11 10 01

SO AS YOU CAN SEE THE PIXELS ARE REPRESENTED BY A BINARY VALUE. THEREFORE THE ABOVE BYTE WOULD BE GREEN (OFF), BLUE, RED AND YELLOW, THE BACKGROUND COLOUR WAS GREEN (COLOR, 0). SO TO DISPLAY THIS YOU SIMPLY LOAD THE BINARY VALUE OF 00101101 OR 45 DECIMAL INTO ADDRESS 7000 HEX.

THIS IS DONE BY:

001 A,45 LD ; NUMBER TO LOAD TO ADDRESS 002 LD (7000H).A :ADDRESS TO LOAD IT TO IT'S THAT SIMPLE!!!!!

PROGRAM NINE - PERSON:

A GOOD EXAMPLE TO SHOW THE USE OF THIS IS TO DRAW A PERSON.

00001 LD A,8 :ENTER MODE(1) 00002 LD (6800H),A HL,7000H 00003 LD DE,7001H 00004 LD 00005 LD BC.7FFH 00006 LD (HL).000007 LDIR A,40 80000 LD ;FIRST CODE 00009 LD (28672), A ; FIRST ADDRESS 00010 LD (28704), A ; SECOND ADDRESS 00011 LD (28768), A ; THIRD ADDRESS 00012 LD (28800), A ; Fourth address LD ;SECOND CODE 00013 A,170 00014 LD (28736),A ;FIFTH ADDRESS 00015 LD (28832), A ; SIXTH ADDRESS 00016 LD B.100 START OF DELAY 00017 DLY LD HL,6000 00018 DLY2 DEC HL 00019 LD A,H00020 OR NZ, DLY2 00021 JP 00022 DJNZ DLY

PROGRAM TEN - FILLER:

7B00H

JP

00023

THIS PROGRAM DEMONSTRATES THE USE OF GRAPHICS AND THE SCANNING OF KEYS. WHEN IT IS RUN IT WAITS FOR THE COMMA KEY TO BE PRESSED. IF THIS IS DONE IT FILLS UP THE SCREEN WITH GRAPHICS UNTIL THE KEY IS RELEASED OR THE END OF THE VIDEO SCREEN IS REACHED. IF THIS HAPPENS OR THE 'Q' KEY IS PRESSED THE PROGRAM JUMPS BACK TO THE ASSEMBLER.

```
00001
            LD
                 A,8
                                       00020
                                                  JR
                                                        Z,STWO
00002
           LD
                 (6800H).A
                                                  CP
                                       00021
                                                        2CH
00005
            LD
                 HL,7000H
                                      00022
                                                  JR
                                                        NZ, SCAN
00004
            LD
                 DE,7001H
                                      00023
                                                  POP
                                                        DE
00005
            LD
                 BC,7FFH
                                      00024
                                                  POP
                                                       HL
00006
           LD
                 (HL).0
                                      00025
                                                  INC
                                                        DE
00007
            LDIR
                                      00026
                                                  INC
                                                       HL
00008
           LD
                 HL,7000H
                                      00027
                                                  LD
                                                        BC,1
           LD
00009
                 DE,7001H
                                      00028
                                                  LD
                                                        (HL).255
00010
           PUSH DE
                                      00029
                                                  LDIR
00011
            PUSH HL
                                      00030
                                                  PUSH HL
00012 SCAN CALL 2EF4H
                                      00031
                                                        HL.77FFH
                                                  LD
00013
           OR
                Α
                                      00032
                                                  RST
                                                        18H
00014
                 Z,SCAN
           JR
                                      00033
                                                  JR
                                                        C,QUIT
00015
           CP
                 51H
                                      00034
                                                  PUSH DE
                 NZ,STWO
           JR
00016
                                      00035
                                                  JP
                                                        SCAN
00017
           JP
                 QUIT
                                      00036 QUIT CALL 1C9H
00018 STWO CALL 2EF4H
                                      00037
                                                  JP
                                                       7800H
00019
           OR
```

LINE ! CLEARS THE VIDEO SCREEN

LINE 8 SETS UP THE VIDEO ADDRESSES

LINE 12 SCANS FOR THE KEYS BEING PRESSED

LINE 15 WAS IT 'Q' (FOR QUIT)

LINE ' 21 WAS IT ', ' (COMMA)

LINE 23 DRAW DOT

LINE 30 CHECK IF END OF VIDEO IS REACHED, IF SO GO TO QUIT

LINE 36 QUIT

PROGRAM ELEVEN - MOVE DOT:

THIS PROGRAM USES THE 'Q A M , KEYS TO MOVE A DOT AROUND THE IF THE SCREEN. TOP OR BOTTOM OF THE SCREEN IS REACHED THE DOT DISAPPEARS BUT IT DOES NOT KEEP GOING. WHEN YOU CHANGE DIRECTION IT REAPPEARS. IF THE SIDES OF THE SCREEN ARE REACHED IT WRAPS AROUND TO THE OTHER SIDE BUT ON THE NEXT LINE.

THE PROGRAM MAKES USE OF LOOPS, CALLS AND RETS, KEY INPUTS AND GRAPHICS. IT COULD BE THE BASIS OF A GAME. (THEY ALL START THE COMMENTS HERE ONLY APPLY TO THE START OF THE SOMEWHERE). ROUTINES. IF YOU STUDY THEM CAREFULLY YOU SHOULD BE ABLE TO FIGURE THEM OUT.

00002	LD LD	A,8 (6800H),A	00019 00020		OR JR	A Z,SCNA
	LD	HL,7000H	00021		CP	41H
	LD	DE,7001H	00022		JR	NZ, SCNM
	LD	BC,2047	00023		JP	DOMN
	LD	(HL),0	00024	SCNM	CALL	2EF4H
	LDIR		00025		OR	Д
	LD	A,40	00026		JR	Z,SCNM
		HL,73FØH	00027		CP	4DH
	LD	(HL),A	00028		JR	NZ,SCNR
		HL	00029		JR	LEFT
	CALL	2EF4H	00030	SCNR	CALL	2EF4H
	OR -	A	00051		QR.	4
	JP.	Z,SCNQ	00032		JR	Z,SCNR
	CP .	31	00033		CP	2CH
		NZ,SCNA	00054		JR	NZ,GCNX
		UP	00055		JR	RIGH
00018 SCNA (CALL	2EF4H	00036	SCNX	CALL	2EF4H

```
LINE 1 CLEARS THE VIDEO SCREEN
LINE 11 SCAN FOR 'Q' BEING PRESSED
LINE 23 SCAN FOR 'M' BEING PRESSED
LINE 35 SCAN FOR 'X' BEING PRESSED
LINE 35 SCAN FOR 'X' BEING PRESSED (EXIT)
LINE 40 MOVE DOT TO THE LEFT
LINE 56 MOVE DOT TO THE LEFT
LINE 72 DRAW DOT IN ITS NEW POSITION
LINE 82 MOVE DOT UPWARDS
LINE 114 JUMP BACK TO THE ASSEMBLER
LINE 118 INCREMENT ROUTINE FOR DOWN
LINE 122 DECREMENT ROUTINE FOR UP
LINE 126 DELAY ROUTINE
```

FOR FOLK WHO WISH TO MODIFY THEIR PRESENT PM DB UNITS AND REQUIRE HELP TO "UNLOCK" IT PLEASE CONTACT MYSELF, THE EDITOR OF THIS MAGAZINE, MR LARRY TAYLOR OR SOME OTHER VZ "SPECIALISTS".

JOHN D'ALTON 39 AGNES STREET TOOWONG QLD 4066 LARRY TAYLOR 4 COLUMBIA COURT SPRINGWOOD QLD 4127 THE EDITOR H V VZ JOURNAL PO BOX 161 JESMOND 2299

ONLY REQUESTS BY MAIL THAT INCLUDE A SSAE ENVELOPE WILL BE ANSWERED.

REFER TO MY PREVIOUS ARTICLE IN THIS MAGAZINE TITLED "UTILITIES FOR DSE. DISC DATABASE" WHERE I OUTLINED SOME VERY USEFUL MODS THAT I HAVE DEVELOPED AND NOW PASS ON TO INTERESTED FOLK.

THE DATABASE UNIT WHICH THE AUTHOR MR. PHIL MAUDE WROTE WAS SOLD BY DSE. HE HAS NOW LIFTED COPYRIGHT ON IT WHICH NOW ALLOWS THESE MODIFICATIONS TO BE MADE. THAT UNIT I CALL PM DB AND FOR THE NEW MODIFICATIONS I SHALL CALL THE UNIT PM DB JD M.

I WILL PRESENT THE ARTICLES IN PRINTED FORM ONLY, NOT ON DISC. IT IS UP TO THE READER TO TYPE IN THE BASIC MODS. YOU WILL NEED TO UNDERSTAND A LITTLE OF THE BASIC LANGUAGE TO PERHAPS DO ANY REQUIRED CORRECTIONS. HOPEFULLY THERE WILL NOT BE TOO MANY "BUGS" FOR YOU TO IRON OUT. THE MODS ARE PROGRAMMED IN BLOCK FORM SO YOU SHOULD NOT HAVE TOO MUCH TROUBLE. THERE ARE SOME PROGRAMMING REMARKS STILL REMAINING AND CAN BE REMOVED IF DESIRED. IN SOME CASES YOU MAY HAVE TO ALTER DIM STATEMENTS AND SUCH LIKE. YOU MAY ALSO HAVE TO INITIALISE NEW VARIABLES THAT I HAVE USED.

I DO NOT ACCEPT ANY RESPONSIBILITY FOR ANY ERRORS IN THE BASIC PROGRAMMES OR FOR ANY LOSS OR CORRUPTION OF DATA FILES. YOU SHOULD MAKE BACK-UP OF ALL FILES IN ANY CASE. IN MY PREVIOUS ARTICLE I NUMBERED THE MODS 1 TO 7. I WILL NOT PRESENT THE MODS IN THIS ORDER. THE MOD NUMBERED 2 WIL BE THE FIRST ONE. SO HERE GOES. BEST OF LUCK.

2. ALTER THE SYSOP DATA

WITH THE ORIGINAL PM DB THERE WAS NO WAY OF ALTERING THIS ONCE IT WAS MADE. IF AFTER SOME TIME (WEEKS/MONTHS) YOU WANTED TO DO THIS, IT MEANT STARTING FROM SCRATCH, SETTING UP A NEW FILE SYSOP AND TYPING IN ALL THE RECORDS DATA AGAIN. SAY YOUR FILE WAS CALLED "AUSTRALIAN STAMPS" AND YOU NEED TO RENAME IT "AUSTRALIAN STAMPS 1" THEN THIS CAN BE DONE ON THE FIRST PROMPT. THE AMOUNT OF CHARS (CHARACTERS) DOES NOT HAV TO BE THE SAME.

THE NUMBER OF PRINTER COLUMNS CAN ONLY BE INCREASED (AT PRESENT). THIS TIES IN WITH THE AMOUNT OF FIELDS, CHARS PER FIELD AND SPACES BETWEEN FIELDS. THE NAME OF ONE OR MORE FIELDS CAN BE ALTERED WITHOUT COUNTING THE LENGTH OF THE NAME. THE LENGTH OF A FIELD CAN BE INCREASED (NOT DECREASED AT PRESENT). ONLY ONE FIELD LENGTH CAN BE ALTERED AT A TIME AND REMEMBER TO CALCULATE THIS IN RELATION TO THE "AMOUNT OF PRINTER COLUMNS".

NOW TO THE MODIFICATIONS

LINES 20. 30 AND 31.

²⁰ DIM FN\$(25),FL(25),L\$(100),F\$(25),N\$(100),D\$(100),LP(20)

^{22 &#}x27;FOR TRANSFER USE DIM N1\$(200), K\$(200), LL\$(200)

³⁰ TL=0:J=0:I=0:X=0:N=0:FL=0:F=0:R=0:A=0

³¹ M1\$="----":REM 31 MINUSES

LINE 9072.

9072 GOSUB 9500: RETURN

THE ACTUAL SECTION THAT ALTERS THE SYSOP THAT YOU TYPE IN:-

LINES 9500 TO 9576.

```
9500 'ALTER FIELD NAMES
9504 CLS:PRINT"FILE NAME = ";FL$
9505 PRINT"AMOUNT OF FIELDS = ";N:LP(1)=1
9507 FOR L=1 TO N:LP(L+1)=LP(L)+1+FL(L)
9509 PRINT"LEFT TAB = "; LP(L); "LENGTH ="; FL(L): NEXT
9514 PRINT: PRINT "ALTER FIELDS OR PRINTER COLUMNS"
9516 INPUT" Y/N ";Q$:IF Q$="N" RETURN ELSE 9518
9518 PRINT"FILENAME IS ";FL$;INPUT"OK Y/N ";Q$
9520 IF Q$="Y" THEN 9524 ELSE 9521
9521 INPUT"TYPE IN NEW FILENAME
          ";FLS:REM 11 SPACES
9524 PRINT AMOUNT OF PRNTR COLS = ";PT:INPUT PRINTER OK Y/N ";Q$
9525 IFQ$="Y"THEN 9530 ELSE INPUT"PRINTER COLS";PT:CLS:GOTO 9530
9530 CLS
9532 FOR Z=0 TO N
9534 PRINT"FIELD ";Z;"IS ";FN$(Z)
9537 NEXT Z
9540 PRINT MIS: INPUT "WHICH FIELD TO ALTER "; Z:PRINT MIS
9542 PRINT"FIELD ";Z;"WAS "FN$(Z)
9543 PRINT"
              FIELD LENGTH = ":FL(Z)
9545 PRINT
9550 PRINT"
               TYPE NEW FIELD NAME"
9552 INPUT"
                     ";FN$(Z):PRINT M1$:REM 8 SPACES
9554 PRINT"FIELD"; Z; "IS NOW "; FN$(Z): PRINT
9560 INPUT ALTER FIELD LENGTH Y/N ";Q$:IF Q$="N" THEN 9565
9562 INPUT TYPE NEW FIELD LENGTH ";FL(Z)
9564 PRINT NEW FIELD LENGTH = ";FL(Z):PRINT M1$
9565 INPUT ADD MORE OR DELETE FIELDS Y/N ":Q$
9566 IF Q$="Y"THEN 9567 ELSE 9570
9567 INPUT "<A>DD MORE OR <D>ELETE ";Q$:IF Q$="A"THEN9568ELSE9569
9568 INPUT "HOW MANY MORE "; Z2:N=N+Z2:CLS:GOTO 9570 9569 INPUT "HOW MANY LESS "; Z2:N=N-Z2:CLS:GOTO 9570
9570 PRINT M1$:PRINT"MORE TO ALTER OR ADD ";
9572 INPUT "MORE FIELDS Y/N ";QS:IF QS="Y"THEN 9500
9574 CLS:PRINT"
                   IS DISC IN DRIVE?": INPUT"
                                                  PRESS RETURN":Q$
9575 SOUND 30,2;20.2:ERA"SYSOP"
9576 GOSUB 9039: RETURN
```

WHEN YOU ARE FINISHED THE OLD SYSOP IS ERASED AND NEW SYSOP IS SAVED.

THE NEXT NORMAL OPERATION OF PM DM IS TO LOAD THE RECORDS FILE. IF WITH PM DB JD M YOU HAVE ALTERED THE LENGTH OF A FIELD, THE NEXT MOD MUST BE TYPED IN. THIS IS LINE 1530. ALSO LINES 1540 TO 1592 AND LINES 9400 TO 9450.

LINE 1530.

1530 SOUND 25,1:0,9:0,9:

LINES 1540 TO 1592

```
1540 'INSERT SPACES & REPACK
1542 CLS:PRINT" ":I-1;" RECORDS WERE LOADED"
1543 PRINT:PRINT" IF A FIELD LENGTH HAS BEEN ALT-ERED AND SAV";
1544 PRINT"ED AS SYSOP, THEN THE EXISTING DATA HAS TO BE ":
```

LINES 1540 TO 1592 CONTINUED

```
1545 INPUT" WAS A FIELD LENGTH CHANGED
                                                 Y/N";Q$
1547 IF Q$="N"THEN GOTO 500
1550 PRINT MIS: INPUT "WHICH FIELD "; FL
1552 INPUT"# OF ADDED SPACES ";SP:SQ$=" ":L$="":SP$="":SR=SP
1556 FOR Z=1 TO SP:SP$=SP$+" "
1560 IF LEN(SP$) < SP THEN 1556
1562 PRINT: PRINT" DATA BEING REPACKED"
1564 FOR I=1 TO R:GOSUB 9400
1566 FOR J=1 TO N
1568 IF J=FL THEN SOS=SPS+" " ELSE SOS=SQS
1570 TS$=L$+F$(J)+SO$:N$(I)=N$(I)+TS$:NEXT J
1571 L$(I) = N$(I)
1583
1585 NEXT I
1588 CLS:PRINT:PRINT:PRINT" NOW TO RESAVE DATA ONTO DISC"
1590 PRINT: INPUT "INSERT DISC & PRESS RETURN"; QS: GOSUB 4000
1592 GOTO 500
1599 END
```

LINES 9400 TO 9450

```
9400 REM UNPACK STRING WHEN FLD LGT ALTERED 9402 SP=SR:L$=""
9410 FOR J=1 TO N:IF J=1 THEN X=1
9412 IF J=FL THEN FL(J)=FL(J)-SP 9420 F$(J)=MID$(L$(I),X,FL(J))
9430 X=1+X+FL(J)
9435 IF J=FL THEN FL(J)=FL(J)+SP 9450 NEXT J:RETURN
```

MR MAUDE DESIGNED PM DB TO "PACK" THE DATA TOGETHER, SEPERATED WITH A SPACE. EI.

FIELD 1 IS 10 CHARS LONG AND FIELD 2 IS 5 CHARS LONG. EI. FIELD 1 DATA IS "SMITH" AND FIELD 2 DATA IS "QLD". BEFORE PACKING THIS IS, (A DASH REPRESENTS A SPACE):-

SMITH-----QLD---AFTER PACKING IS:-SMITH-QLD-

NOW IF YOU ALTERED THE LENGTH OF FIELD 1 FROM 10 TO 15 THEN THE EXTRA 5 SPACES MUST BE FITTED INTO THAT FIELD. IF THE WORD IS "THOMASETI" THEN 6 EXTRA SPACES ARE PACKED IN, PLUS THE END OF FIELD (EOF) SPACE.

AFTER THE RECORDS FILE HAS BEEN LOADED YOU ARE ASKED IF A FIELD LENGTH HAS BEEN ALTERED. IN THIS CASE ANSWER YES. YOU THEN TYPE IN THE AMOUNT OF EXTRA SPACES, EI, 5 IN THIS CASE. THE RE-PACKING OF THE FIELD ALTERED OF ALL THE RECORDS IS NOW DONE. EVERY FIELD AFTER THE FIELD ALTERED IS MOVED TO THE RIGHT BY 5. THIS IS CARRIED OUT TO EVERY RECORD. SO IF THE END OF THE RECORD COUNTED TO 90 CHARS, IT WOULD NOW BE 95. UNDERSTAND?

THIS RE-PACKING TAKES A MINUTE OR SO, DEPENDING ON THE NUMBER OF RECORDS ON THE FILE. THE OLD FILE IS ERASED AND THE NEW FILE IS SAVED. GO STAIGHT TO THE "PRINT FILE" ON PRINTER AND ALL SHOULD BE OK. TEST ON A SMALL FILE OF SAY 5 RECORDS AT FIRST. IF ALL OK THEN ANOTHER FIELD LENGTH CAN BE ALTERED TO RECHECK.

AS MENTIONED IN LAST ISSUE THE AVAILABILITY OF CHEAP LARGE CAPACITY MEMORY DEVICES BOTH STATIC AND DYNAMIC CAN EXPAND THE VZ HORIZONS WITH COMPATIBILITY OF PREVIOUS EXPANSIONS AND STANDARDS CONSIDERABLY. IN MIND I PROPOSE AND ADD THE FOLLOWING STANDARDS:

- C000H-FFFFH - OUTPUT PORT A112-A127 - 16K BANKS MAIN MEMORY - 8000H-9FFFH - OUTPUT PORT A216-A231 -AUTO BOOT 8K BANKS SUPER GRAPHICS - 7000H-77FFH - OUTPUT PORT A32-A47 -2K BANKS RDOS - 6000H-67FFH - OUTPUT PORT A232-A247 -2K BANKS RAMDISK - 4000H-5FFFH - OUTPUT PORT A248-A255 -8K BANKS

AUTO BOOT = MORE ON IT NEXT ISSUE.

= RAM DISK OPERATING SYSTEM. WILL CONTROL RAMDISK AND ITS RDOS

DATA STORAGE/RETRIEVAL OPERATIONS.

RAMDISK = VERY FAST MEMORY BASED PROGRAM & DATA STORAGE/RETRIEVAL

AREA SIMILIAR TO DISK DRIVE.

NOTE: ANY COMMENTS ON ABOVE PLEASE CONTACT THE EDITOR.

PHAP	PROP	SED VZ 200/300	EXPANDE	HEMORY MAP	JOE LEON I
65535	TOM - TOP OF	MEMORY = 65535	FFFFH		FFFF
63488	2K NOT USED		F800H	TOM = 65535	
	VZ 300 16K MEHORY EXPANSION	12K NOT USED		160K MEMORY EXPANSION 32K X 8 BIT 128K X 8 BIT STATIC RAMS	
53348	CARTRIDGE	TOM = 53347	рооон	10 X 16K BANKS OUT A112-A127	
49152			сооон		cooo
45134	*AU _ 2P1A4		веоон		
40960	TOM = 45183	VZ 200 16K HEHORY EXPANSION CARTRIDGE	АДДДН		A000l
	USER RAM			FUTURE MEHORY	
36864		TOM = 36863	9000Н	EXPANSION ? AUTO BOOT CARTRIDGES 32K OR 128K X 8 BIT STATIC RAMS	
32768		VZ 200 6K	- ADDOH	4/16K X SK BANKS	80001
30720	OF UPBEA W	USER RAM	7800H		7800
28672	2K KEYBOARD,	ISPLAY RAM	7000H	SUPER GRAPHICS OUT A32-A BK SRAM 4 X 2K BA	
26624		DP CONTROL	6800H	RDOS/XDOS OUT A248-A	6800
24576	2K EXTENDED DOS		6000H	32K SRAM 16 X 2K BAI	
	10K RESERVED FOR CARTRIDGES 8K DOS ROM			RAMDISK 129K X 8 BIT STATIC RAM	
16384	BR VZT 4K MAGI	ERMINAL	4000H	16 X RK BANKS OUT A232-A247	4000
	BASIC INTERPRETER 16K ROM			BASIC PSEUDO ROM 32K X 9 BIT STATIC RAM 2 X 16K BANKS HANUAL SWITCHING	
00000			оооон		10000

LOOK !!!! --- PROGRAMS FOR SALE --- ALL NEW !!!!

WHAT, ANOTHER DISASSEMBLER? BUT, YOU HAVE ALREADY GOT ONE? THIS ONE IS DIFFERENT!

THIS PROGRAM IS ENTIRELY WRITTEN IN MACHINE CODE. IT ACTUALLY RUNS ABOUT 40 TIMES FASTER THAN D.S.E.'S DISASSEMBLER (OR ANY ONE ELSE'S). IT WILL DISASSEMBLE ANY PROGRAM THAT YOU CAN BLOAD INTO MEMORY. IT WORKS WITH ANY VZ CONFIGURATION. IT DISASSEMBLES EVEN THE 88 EXTRA Z80 OPCODES THAT ZILOG DOESN'T ADMIT TO.

PRICE? ONLY \$25.00 - TAPE AND DISK VERIONS AVAILABLE.

PRICE INCLUDES HARDCOPY MANUAL. INTERESTED? YOU MAY PURCHASE THIS PROGRAM FROM PETER HICKMAN, FOR ADDRESS SEE BELOW.

BRAND NEW - VZ SERIAL INTERFACE PROGRAM - BRAND NEW

DID YOU WANT TO TALK TO OTHER COMPUTERS VIA A MODEM? DID YOU BUY THE DSE TERMINAL EPROM, ONLY TO DISCOVER THAT IT ONLY WORKS WITH TAPE. IT ONLY ALLOWS YOU TO PRINT FILES, NOT SAVE THEM OR SEND THEM!

YOUR PROBLEMS ARE SOLVED! THE HICKMAN BROTHERS, PETER AND ANDREW, HAVE A BRAND NEW PROJECT WHICH WILL ALLOW YOU TO SEND, RECEIVE & SAVE FILES VIA A MODEM. IT WORKS WITH DISK!

SALE PRICE \$25.00 ONLY

INCLUDED ARE INSTRUCTIONS FOR THE HARDWARE MODIFICATIONS.

A SMALL MODIFICATION IS NEEDED TO YOUR DISK CONTROLLER. YOUR USER GROUP MAY HELP YOU MODIFY YOUR COMPUTER TO USE THIS EXCITING NEW SOFTWARE! IF YOU HAVE THE FUNCTION KEYS MOD AS WELL, THEN YOU WILL BE ABLE TO SEND EXTRA ASCII CHARACTERS SUCH AS:-

{ | } ~_

THE MANUAL IS SUPPLIED ON DISK FOR YOU TO PRINT OUT WITH YOUR DISK VERSION OF E & F WORDPROCESSOR. IF YOU DO NOT OWN AN E & F WORDPROCESSOR PROGRAM, PLEASE ENCLOSE ANOTHER \$5.00 (TOTAL \$30.00) FOR PHOTOCOPYING AND POSTAGE OF THE MANUAL.

FOR PURCHASE OR MORE INFORMATION CONTACT:PETER HICKMAN P.O. Box 8, WERRINGTON N.S.W. 2747.

PATCH 3.3 WRITTEN BY DAVE MITCHELL WILL CONVERT YOUR E & F TAPE WORD PROCESSOR FOR FULL DISK USE WHILE RETAINING ALL ORIGINAL FUNCTIONS. BELOW ARE ADDED DISK COMMANDS & FUNCTIONS :-

LOAD, SAVE, ERASE, RENAME, DIRECTORY, INITIALIZE, UPDATE, DRIVE 1 & 2, SHIFTLOCK & IMBEDDED PRINTER CONTROL CODES PLUS CTRL+P WHICH BYPASSES PRINT MENU AND PRINTS TO SCREEN OR PRINTER. A ROUTINE IS ALSO PROVIDED TO CONVERT YOUR BASIC PROGRAM OR SOURCE CODE FILES INTO WORD PROCESSOR FILES.

PATCH 3.3 HAS PROVISION FOR IMBEDDING PRINTER CONTROL CODES IN TEXT AND FAST SAVING AND LOADING OF TEXT DATA TO AND FROM DISK USING BLOCK SAVE/LOAD TECHNIQUES. PRINTER CONTROL CODES CAN BE SAVED TO TAPE OR DISK.

BSTWP.F - THIS UTILITY PROVIDED WITH PATCH 3.3 WILL CONVERT BASIC PROGRAMS AND ED/ASS. SOURCE CODE FILES INTO WORD PROCESSOR FILES.

SYSTEM REQUIREMENTS - VZ 300 + 16K RAM PACK - VZ 200 + 26K

PATCH 3.3 IS COPYRIGHT TO AND ONLY AVAILABLE FROM :- HUNTER VALLEY VZ USERS' GROUP P.O.BOX 161 JESMOND 2299 N.S.W. AUSTRALIA - PHONE JOE LEON (049) 51 2756

PRICE - AUS/NZ AU\$20.00 - UPDATE - AUS-\$10.00 - NZ-AU\$11.00. UPDATING AVAILABLE ONLY TO PREVIOUS PURCHASERS OF PATCHES.

FOR MORE INFORMATION WRITE TO H.V.VZ.U.G. ENCLOSING A SSAE.

EXTENDED DOS V1.3 - \$15.00

UPDATED VERSION WITH EXTRA COMMANDS ADDED :-

OLD COMMANDS - MERGE, DIRA, LDIRA, DIRB, LDIRB, OLD, OLD., DEC, HEX, STATUSA AND LSTATUSA. STATUSA AND LSTATUSA ALSO WORKS WITH VERSION 1.0 DOS.

NEW COMMANDS :-

LTAB

MENU - LOADS AND RUNS BINARY OR TEXT MENU PROGRAM FROM DISK.

CODE - SIMPLIFIES USING PRINTER CONTROL CODES DIRECTLY OR FROM

WITHIN A PROGRAM.

- IS FOR SETTING OF LEFT MARGIN.

MOVE - Moves Basic file from disk to chosen memory adoress.

UPD - ERASES OLD FILE AND SAVES WITH SAME FILE NAME.

MENU/FILE COPIER - \$15.00

THIS UTILITY WILL READ YOUR DISK DIRECTORY AND PRESENT YOU WITH SEVERAL OPTIONS. USING THE CURSOR YOU CAN RUN/BRUN ANY PROGRAM OR SELECT FILE COPY. REN. ERASE, DRIVE 1 OR 2, ETC. BESIDES COPYING TEXT AND BINARY FILES ALL OTHER FILES CAN BE COPIED AS WELL EXEPT FOR DATA FILES.

FOR PURCHASE OR INFORMATION CONTACT DAVE MITCHELL - (079) 27 8519 24 FURHINSTONE ST. NORTH ROCKHAMPTON QUEENSLAND 4701

FOR INFORMATION OR DEMONSTRATION IN NEWCASTLE AREA CONTACT :- JOE LEON - (049) 51 2756 - 22 DRURY STREET WALLSEND NSW 2287

CONTRIBUTIONS TO THE HUNTER VALLEY VZ JOURNAL :-

IF YOU ARE THINKING OF CONTRIBUTING TO THE JOURNAL THE PREFERED FORMAT IS BASIC LISTINGS, WORD PROCESSOR OR SOURCE CODE FILES ON TAPE OR DISK. FILES FROM THE FOLLOWING WORD PROCESSORS CAN BE ACCEPTED :-

E & F TAPE OR DISK PATCH 3.1-3.3, WORDPRO CARTRIDGE, WORDPRO PATCH, MOST SOURCE CODE FILES AND ALL QUICKWRITE WORD PROCESSOR FILES.

* * CLUB MEETINGS - ALL WELCOME * *

FIRST FRIDAY OF MONTH - NO MEETING IN JANUARY 1991

VENUE - JESMOND NEIGHBOURHOOD CENTRE MORDUE PARADE JESMOND (REAR STOCKLAND MALL - BIG W)

DECEMBER 7 - REVIEWING 1990 & PREVIEWING 1991

BASIC - MACHINE CODE & ASSEMBLY CONTINUED

CHRISTMAS PARTY - BRING FAMILY - FRIENDS - PLATE

HOT & COLD LIQUID REFRESHMENTS PROVIDED - ALL WELCOME

JANUARY 4 - NO MEETING

FEBRUARY 1 - BASIC - MACHINE CODE & ASSEMBLY CONTINUED DEMO - IF READY 320K MEMORY EXPANSION NOTIFIED IN NEXT ISSUE IF OTHERWISE

FUTURE DEMONSTRATIONS -

EPROM PROGRAMMER & ERASER, AUCTION NIGHT - USING THE VZ, RITTY, ETC. IF YOU HAVE ANY IDEAS FOR A DEMONSTRATION OR A SUBJECT THEN PLEASE LET YOUR COMMITTEE KNOW.

CLUB COMMITTEE & SUBSCRIPTIONS -

PRESIDENT ----- ROSS WOODS --- (049) 71 2843 SECRETARY/EDITOR -- JOE LEON ---- (049) 51 2756 TREASURER ----- GARY BULLEY -- (049) 54 7561 COMMITTEE MEMBERS - COLIN BRIDGE - PETER JONES

SUBSCRIPTION TO - AUST. - 6 MONTHS \$11.00 - 12 MONTHS \$21.00 H.V.VZ.JOURNAL - N. Z. - 6 MONTHS \$13.00 - 12 MONTHS \$26.00 NOTE: PRICES INCLUDE POST & PACKING

HUNTER VALLEY VZ USERS' GROUP - PO BOX 161 JESMOND 2299 NEW SOUTH WALES AUSTRALIA

VZ USER GROUPS & PUBLICATIONS --

VZ DOWN UNDER - VZ MAGAZINE - 6 ISSUES - \$18.00 PER ANUM HARRY HUGGINS 12 THOMAS SREET MITCHAM VICTORIA 3132

WAVZ - WESTERN AUSTRALIA VZ USER GROUP GRAEME BYWATER P O BOX 388 MORLEY W A 6062

BRISBANE VZ USERS WORKSHOP - C/O 63 TINGALPA ST. WYNUM WEST 4178 SOFTWARE FOR SALE - DISK MENU

SAPPHIRE PRODUCTIONS - VZ DISK MAGAZINE - \$20.00 PER ANUM CONTACT JASON OAKLEY PO BOX 600 TAREE NSW 2430

NOTE: WHEN WRITING TO ANY ABOVE OR H.V.VZ. USERS' GROUP FOR INFORMATION PLEASE ENCLOSE A S.S.A.E. OR NZ 2 INT. REPLY COUPONS.