# A VZ-Epson printer patch — the search continues Larry Taylor

## Part 2

IN THE PREVIOUS instalment, printing of the VZ's inverse and graphics characters had been made possible. At this point, the ideal enhancement to our printer patch would be to enable the VZ's COPY command to function correctly when matched with an EPSON type printer. This should be possible, but we must first examine why the usual means for intercepting BASIC key words, during programme execution, won't work in the case of the COPY command.

The VZ's ROM owes much to that used in the earlier TRS-80 computers. The COPY routine, however, is one of a number of additions which greatly enhance the VZ's capabilities. As such, it contains none of the DOS exits, which are to be found in the older sections of the ROM. These exits, or "vectors", are calls to an area in the communications area of RAM, and provide the means by which some BASIC commands may be altered or redirected. Since the VZ DOS makes no use of these vectors, none have been provided in the newer sections of the ROM. My initial hopes dashed, I began to investigate the method used to integrate the DOS into the VZ's operating system. In doing so, I uncovered an alternative vector, one which would make it possible for us to not only intercept the COPY command, but also open the door to further enhancements to the VZ's BASIC.

#### How so?

It is important to understand, initially, why this type of modification is possible. When we write a BASIC programme, we are creating what we hope will be a precise set of instructions. Unfortunately, before the computer can understand and respond to our commands, each instruction in turn has to be painstakingly translated or intrpreted. This is the reason for BASIC's slowness, and it can really only be effectively overcome by having the programme translated or compiled prior to execution. Yet, because a BASIC programme is interpreted as it runs, it is possible that additional commands may be added to the language, provided they are intercepted and executed prior to reaching the VZ's own interpreter. This is precisely what happens when a disk operating system is added. New commands enabling disk operations to be performed, supplementing the existing BAS-IC. In the case of the COPY command, we are seeking to redirect it to a routine compatible with EPSON type printers, and on completion, have it return as though all had proceeded


As I undertook to produce this extension to the patch, I found myself venturing much further than I had originally intended. The project involved modifying the existing ROM routine, as well as enhancing the COPY command to provide for a second screen dump routine of my own design. Furthermore, I allowed for a copy of the LO-RES screen without the usual linefeeds. I also sought to eliminate those unfortunate flaws in the inverse character data. Listing 1, which was kindly supplied by Bob Kitch, enables a closer examination of the inverse characters held in ROM, by displaying them on the HIRES screen. By relocating the ROM table to RAM at the top of memory the necessary modifications to the data have been made possible.

74 — Australian Electronics Monthly — June 1987

VZ ROM, INVERSE CHARACTER SHAPE TABLE



VZ ROM, PRINTER PATCH MODIFIED TABLE



(note changes to underlined characters)

The accompanying illustration allows a comparison to be made between the ROM characters, at top, and those in the shape table addressed by the printer patch. Incidentally, should you decide that you still don't like the look of the amended characters, it is possible, using the same approach, to either further refine them, or even custom design a completely new set.

Inspired at having overcome this obstacle, and because I have written a number of programs using an Extended BAS-IC, I wanted the routine to be able to list those commands, which would not normally be recognised. The final aim was to deal with the printer's unimpressive performance, signalled by a dramatic decrease in speed, each time it had to print a graphics or inverse character. The solution I chose to minimise these delays was to feed the data into a section of RAM, which would act as a collection area or buffer, prior to printing. A discussion in detail of how each of these refinements was implemented would only serve to complicate what is otherwise a relatively straightforward procedure. I have elected, instead, to demonstrate how to intercept and enhance an existing keyword on a smaller scale by using another of the VZ's commands.

# Enhanced CLS

Tandy's Colour Computer has an enhanced CLS command which enables the user to clear the screen to any one of nine background colours. The syntax is CLSn, where n may be a number in the range 0-8. To illustrate how enhancements to the existing language can be accomplished, this command will be necessary to examine further how the VZ operates.

When a BASIC program is RUN, control passes to a machine language ROM routine, the Execution Driver at 1D5AH, which scans each line of the BASIC programme as it comes to it and begins to translate it. Part of the translation process involves looking for tokens. These are values in the range 128-250 (80H-FAH) that take the place of BASIC reserved words e.g. CLS = 132 (84H). Once the word has been identified and checked for correct syntax, control is passed to the corresponding ROM routine before returning to continue the translation.

On power-up, the address of the routine which examines each byte in a line of BASIC, is stored at 7804H. This is the vector hinted at earlier, and in a non-disk VZ it will normally contain a pointer to the RST 10H routine at 1D78H. Because this vector is in RAM it can be easily changed. This was done so that at a later stage the DOS could be included.

At least three different versions of the VZ DOS could be included that I am aware of, and two of these display the same version number on power up. Consequently, the only fixed location common to all three versions is a jump table commencing at 4005H. This makes it difficult to refer to an actual address within the DOS, where command processing is carried out. However, since all processing must be channelled via the above-mentioned vector, a peek at this address will uncover the whereabouts of the DOS interpreter. A close examination of this region of the DOS will reveal how the added disk commands are interpreted and implemented. This information will enable us to introduce into the system an enhanced command of our own choosing. The trick is to ensure that, as far a the VZ's interpreter is concerned, nothing unusual has happened.

The accompanying assembly language programme in Listing 2, with its associated comments, shows in greater detail how this is accomplished. If you do not have access to an Editor Assembler, Listing 3 is a BASIC version, which pokes the routine into memory. Having adjusted the top of memory pointer, the address at 7804H is stored and replaced by our own. The programme then locates the new routine at the top of the memory. Now each time a byte is to be examined during execution it must first pass through our checkpoint. Once the origin of the call is established, the routine looks for the CLS token, 132 (84H).

Only when it has been located does the routine proceed to examine the next byte. This is checked to see if it lies in the range 0-9. Once it has passed this test, the clear screen routine is implemented, after first calculating the appropriate value, with which to fill the screen. You will notice that not only is it necessary to check for the new command, but also to provide the routine which implements it. In this case a simple block load to the screen has been used. Control is then returned to the ROM processing routine, which prepares to examine the byte following ournew command. So, as far as the VZ knows, everything is continuing normally. Tricky isn't it?

The VZ will now respond to the CLSn command, when entered, either directly from the keyboard, or from within a program, with one exception. For some unexplained reason, during IF-THEN-ELSE processing the ROM accesses the byte examine routine at 1D78H directly, instead of via a RST 10H call. This means there is no efficient method for our programme to intercept the new command, when it is used in an IF-THEN-ELSE statement. The problem can best be

```
LISTING 1
                                                                             OFFICE OF SET IN SOM

SET IN SOM

AS USED BY DOT MAIRIX

FRINTER
                                                                             R. B. KITCH 27/1/66 ***
         60
          70
                         WHEN INVERSE CHARACTERS ARE SENT ID A DOT MATRIX PRINTER
THE PRINTER SHIFTS TO GRAPHICS MODE AND REGUIRES A ROUTINE
TO SUPPLY THE AFFROPRIATE SHAPES TO THE HEAD. INORMAL
CHARACTERS ARE HELD IN THE FRINTERS ROM)
IN THE VZ COMPUTER A TABLE OF SHAPES IS LOCATED AT
35F4H TO 3CD3 IN ROM. THERE ARE 64 CHARACTERS, EACH USING
5 BYTES TO DEFINE THEIR GRAPHIC SHAPE. THE SHAPES MAY BE
DECODED AND OUTPUT TO THE SCREEN AS IS DONE IN THIS
PROGRAM. NOTE THAT THERE ARE SOME ERRORS IN THE ROM.
THE 5 BYTES DEFINE A 5 BY B DOT MATRIX WHICH IS THE SHAPE
OF THE CHARACTER, WHICH INCIDENTALLY ARE NOT ORDERED
ACCORDING TO THE ASCII CODE.
THE FIRST BYTE DEFINES THE LEFT HAND EDGE OF THE CHARACTER—
WHICH IS THE FIRST PRINTED DURING A PASS OF THE PRINTER
HEAD. IN TANDY PRINTERS THE MEB IS THE LOWERMOST PIN OF THE
HEAD AND THE LESS IS THE UPPERMOST PIN. THE PINS ON EPSON
PRINTER HEADS ARE ARRANGED IN THE OPPOSITE SENSE. THIS
REQUIRES THAT THE BITS IN EACH BYTE BE REVERSED.
          100
         150
       200
       210
       270 DIM MKX(7) : '***VECTOR OF BIT MASK VALUES - POWERS OF 2
310 DIM BTX(7) : '***VECTOR OF DECODED BITS FROM ROM VALUE.
     320 ****FILL MASK VECTOR WITH POWERS OF 2 FOR DECODING. 340 FOR 1%=0 TO 7 :MK%(1%)=2^1% :NEXT 1%
     400 ****INITIALIZE PARAMETERS - MAY BE CHANGED TO VARY SCREEN.
   400 CCZ4 : '***CHARACTER COLDUR. (1-4)
420 BC%-2 : ***BACKGROUND COLDUR. (1-4)
430 CSX*-0 : '***COLDUR WIDTH BETWEEN CHARACTERS.
450 SFX*-16 : '***COLDUR WIDTH BETWEEN CHARACTERS.
450 SFX*-16 : '***COLDUR SET. (0-1)
460 HSX*-0 : '***COLDUR WIDTH BETWEEN CHARACTERS.
450 SFX*-16 : '***STARTING HORIZONTAL POSITION ON HI-RES SCREEN.
470 VP%-3 : '***STARTING VERTICAL POSITION ON HI-RES SCREEN.
480 HMX=127 : '***MAXIMUM HORIZONTAL POSITION. (0-127)
490 '***
                    ***SET UP MAIN LOOP TO STEP THROUGH ROM FROM 3894H-3CD3.

BK%=0 : ***BYTE COUNTER FOR EACH CHARACTER.

HP%=MS% : ***SET HOR1ZONTAL POSITION TO START

MODE(1) :COLOR,CS% : ***SET HOR1ZONTAL POSITION TO START

****SET UP MAIN LOOP TO START

****SET HOR1ZONTAL POSITION TO START

*****SET HOR1ZONTAL POSITION TO START

****SET HOR1ZONTAL POSITION TO START

*****SET HOR1ZONTAL POSITION TO START

****SET HOR1ZONTAL POSITION TO START

****SE
     600
     610 BK%=0
     620 HP%=HS%
630 MODE(1) :COLOR,CS%
     640 SM%=15252
     650 EM%=15571
660 FOR AD%=SM% TO EM%
                     ****DECODE THE INDIVIDUAL BITS OF DV% AND STORE IN BT%().

****THE MASK VALUES IN MK%() ARE "ANDED" WITH THE VALUE.

***THE RESULT STORED IN BT%() IS THE "COLOUR" OF THE BIT.
FOR 1%= 0 TO 7 : ****FROCEED FROM LSB TO MSB.

IF DV% AND MK%(1%) THEN BT%(1%)=BC% ELSE BT%(1%)=CC%
NEXT 1%
     800
810
                      ***CHECK THAT THERE IS ENDUGH ROOM TO PLOT CHARACTER.

IF BK%=0 AND HM%-HP%<4 THEN HP%=H5%: VP%=VP%+5P%: *NEW ROW

EK%=BK%+) : ***INCREMENT BYTE COUNTER.
     820
   E30
E40
900
910
                       ****OUTPUT BYTE TO SCREEN. FOR 1%=0 TO 7
                                 COLOR BT% (1%)
    920
                                                                                                                                 : '***SET COLOUR OF BIT.
   930
940
950
1000
                                                            (HP%, VP%+1%)
  950

***PREFARE FOR NEXT BYTE.

1010 HP%=HP%+1 : ****INCREMENT HORIZONTAL POSITION.

1020 IF BK%=5 THEN BK%=0 :HP%=HP%-CW% : ***NEW CHARACTER.

2000 GDTD 2000 :END
     LISTING 1A
                   THIS SHORT LISTING CAN BE USED BY OWNERS OF THE PRINTER PATCH TO CALCULATE THE START AND END LOCATIONS OF THE REVISED INVERSE CHARACTER SHAPE TABLE IN THE COMPLETED VERSION. BY SUBSTITUTING THE NEW VALUES FOR THOSE WHICH APPEAR IN LINES 640 AND 650 OF LISTING 1, THE MODIFIED CHARACTERS CAN BE DISPLAYED ON THE HIRES SCREEN.
                     ***CALCULATE THE TOP OF MEMORY
 190 TM=PEEK (30897) +256+PEEK (30898 200 1F TM)32767 THEN TM=TM-65536
 200 FREND OFFSET TO TOP OF MEMORY TO LOCATE START OF TABLE 230 SMX=TM+666 : ****START OF SHAPE TABLE.

250 FREND 64 CHARACTERS X 5 BYTES TO LOCATE END OF TABLE
240 '
250 '###ADD 64 CHARACTERS X 5 BYTES TO LOCATE END OF TABLE
260 EMX=SMX+64+5-1 : '+++END OF SHAPE TABLE
270 "###PRINT START AND END ADDRESSES
290 PRINT"START - SMX="; SMX
300 PRINT"END - EMX="; EMX
```

overcome, by means of a minor change in syntax, when entering the programme line. Using the line,

## 100 IF X = 4 THEN CLS4

should clear the screen to red, when X = 4.

What actually happens is that the screen clears normally, followed by a SYNTAX ERROR message, indicating the routine at 1D78H has not recognised our enhanced command.

```
LISTING
  0005 ;
0006 ;THIS SECTION RELOCATES
0007 ;THE PROGRAM TO THE TOP
0008 ;CF AVAILABLE MEMORY.
0009 ;
                                                                                                               ;SET VCTR AS 7A28H
;LOAD STACK POINTER
;GET THE TOP OF MEMORY
;GET LENGTH OF PROGRAM
;SAVE PROGRAM LENGTH
;RESET ALL FLAGS
;TAKE LENGTH FROM TOP OF MEMORY
;LOAD NEW TOP OF MEMORY
;SAVE NEW TOP OF MEMORY
;RESET ALL FLAGS
;RESERVE SO BYTES STRING SPACE
;TAKE SPACE FROM TOP OF MEMORY
;LOAD START OF STRING SPACE
;RETRIEVE TOP OF MEMORY
  0010 VETR EQU 7A28H
                                      TD TD
                                        LD SP,7700H
LD HL,(7881H)
LD BC,ENDP-NVCT
PUSH BC
  0011
  0012
                                       XOR A
SBC HL,BC
LD (7881H),HL
   0015
  0016
  0017
                                       LD (7881H),HL
PUSH HL
XOR A
LD BC,33H
SBC HL,BC
LD (78A0H),HL
  0019
0019
0020
0021
  0022
                                        LD
POP
                                                                                                                LOAD START OF STRING SPACE
RETRIEVE TOP OF MEMORY
INCREASE BY ONE
GET CURRENT RSTIOH VECTOR
STORE IT IN 7428H
LOAD NEW VECTOR
GET START OF PROGRAM TO MOVE
RETRIEVE PROGRAM LENGTH
MOVE TO NEW LOCATION
1DO A NEW
JUMP TO READY MESSAGE
                                                      DE
  0023
                                       POP DE
INC DE
LD HL,(7804H)
LD (VCTR),HL
LD (7804H),DE
LD HL,NVCT
POP BC
  0024
  0027
                                       LD
POP
LDIR
  0028
0029
  0030
                                       CALL 1B4DH
JP 1A19H
0033 ;
0034 ;START OF THE PROCESSING
0035 ;ROUTINE FOR NEW COMMAND.
                                                                                                                 ; SAVE ALL REGISTERS
; CHECK TO
; SEE IF THE
                                    EXX

LD HL,1D58H

POP DE

OR A

SBC HL,DE

PUSH DE

EXX

JP NZ,1D76H

PUSH HL

CALL 1D78H

JR NZ,CONT

POP HL

LD DE,(VCTR)

PUSH DE
  0038
 0039
  0040
                                                                                                                   RETURN
                                                                                                                 ; RETURN
; ADDRESS
; IS 1058H
; RESTORE ALL REGISTERS
; IF NOT GO TO NORMAL PROCESSING
; SAVE STRING ADDRESS
; GET NEXT VALUE FROM STRING
; IF NOT ZERO THEN CONTINUE
; ELSE RESTORE STRING ADDRESS
; RETRIEVE DRIGINAL VECTOR
 0040
0041
0042
0043
0044
  0046
  0047
                                       PUSH DE
 0050
                                                                                                                  ; AND JUMP
; TO IT
                                                                                                               ; AND JUMP;
; TO IT
; CHECK FOR CLS TOKEN
; IF NOT FOUND RETURN TO CALLER
; MOVE TO NEXT VALUE IN STRING
; GET NEXT VALUE AFTER CLS TOKEN
; REDUCE IT TO RANGE 0-8
; IF ZERO THEN EXECUTE COMMAND
; LOAD B REG WITH UPPER LIMIT
; CHECK IF A=8
; IF YES THEN EXECUTE COMMAND
; REDUCE B AND CONTINUE CHECK
; NO MATCH SO RETURN TO CALLER
; RETRIEVE OLD STRING ADDRESS
; RETRIEVE OLD RETURN ADDRESS
; LOAD NEW RETURN ADDRESS
; SAVE NEW RETURN ADDRESS
; MOVE TO NEXT VALUE IN STRING
; SAVE CURRENT STRING ADDRESS
; MULTIPLY CLS
; MULTIPLY CLS
 0051
  0052 CONT CP
                                      CP B4H
JR NZ,POP
INC HL
LD A,(HL)
SUB 3OH
JR Z,EXEC
 0057
0057 JR Z,EXEC
0058 LD B,8
0059 CMPR CP B
0060 JR Z,EXEC
0061 DJNZ CMPR
0062 JR POP
0063 EXEC POP DE
 0064
                                       POP DE
                                     POP DE
LD DE,1D1EH
PUSH DE
INC HL
PUSH HL
ADD A,A
ADD A,A
ADD A,A
ADD A,A
ADD A,A
IR NZ,SKIP
0064
0065
0066
0067
0068
0069
                                                                                                                 MULTIPLY CLS
VALUE BY 16 TO
CALCULATE THE
COLOUR OFFSET
 0070
 0071
                                                                                                                 ; IF RESULT NOT ZERO THEN SKIP
; IF ZERO INCREASE TO ONE
; ADD 127 TO GET GRAPHICS BLOCK
0074 INC A
0075 SKIP ADD A,7FH
0076;
0077; CLEAR SCREEN ROUTINE
0077;0
0078;
0079
0080
0081
0082
                                                                                                               ;LOAD START OF SCREEN ADDRESS;SET CURSOR POSITION;LOAD START OF SCREEN PLUS ONE;NUMBER OF BYTES TO MOVE;LOAD GRAPHICS BLOCK INTO HL;DO A BLOCK FILL OF THE SCREEN;RETRIEVE STRING ADDRESS;RETURN TO 101EH TO CONTINUE
                                                 HL,7000H
(7820H),HL
DE,7001H
BC,01FFH
                                      LD
LD
                                     LD (HL),A
 0083
 00B4
0085 POP HL
0086 RET
0087 ENDP DEFB 0
```

To have the command function properly, insert a colon between the THEN and the new command as below,

END OF PROGRAM MARKER

### 100 IF X = 4 THEN:CLS4

Now, when X = 4 the THEN part of the statement will be executed, including, as is usual, any additional commands in. the remainder of the line. However, once the colon is reached, the BASIC ROM returns to its usual processing, via the RST 10H routine, and the CLS4 command is then interpreted on its own and not as part of the IF-THEN statement. This is the same solution suggested in the VZ-DOS manual, when using disk commands, which are affected in exactly the same way.

This is essentially the approach I have used to produce a 3 of 3

```
LISTING 3
```

VZ-EPSON Printer Patch, which enables all the normal printer functions for Epson or Epson-compatible printers. As well as providing the ability to LLIST and LPRINT all inverse and graphics characters, the COPY command is intercepted by the patch. As a result, its function has been enhanced to allow a proper dump of both the LO-RES and HI-RES screens. Corrections have been made to the flawed inverse character data, and when listing, the routine is capable of recognising all the hidden commands, which may have been entered using an Extended BASIC. The patch relocates to the top of available RAM and can be used with Steve Olney's EXTENDED BASIC, already resident in memory, enabling ready access to the functions of both. I hope that the techniques used here to produce what I have found to be an extremely useful utility will encourage others to attempt further such developments.

Perhaps additional enhancements to the VZ's BASIC could be explored. The Commodore 64 is served by a number of enhanced BASICs, why not the VZ? Programs which make use of such BASICs require that the language be loaded before they will function properly. However, this is little different to programs using disk commands needing the DOS to be interpreted correctly. Certainly, the opportunity exists to endow the humble VZ with a brand new bag of tricks.

For anyone interested, copies of the completed VZ-Epson Printer Patch, may be obtained on tape for \$15, from:

```
J.C.E. D'Alton
VSOFTWAREZ
39 Agnes St
Toowong
Qld 4066
```